

Audio/Visual equipment supplied by:



OUC Youth

believe. belong. become.



Apple TV [HDMI CableB]




TV Display
HDMI 3



Sound Bar
D. In

1. Ensure that the Apple TV is connected with [HDMI Cable B] provided.
2. Turn on the TV display by pressing the **ⓘ/I** button.
3. Press the **INPUT** button on the front of the *Toshiba TV* to set the Input to **HDMI 3**



4. Turn on the Soundbar by pressing the **ⓘ** button. Then press the **F.** button on the top of the *Samsung Soundbar* or the [**SOURCE**] button on the remote control to set the mode to **D.IN**



Audio/Visual equipment supplied by:



OUC Youth

believe. belong. become.



Laptop [HDMI Cable B]




TV Display
HDMI 3



Sound Bar
D. In

1. Connect the laptop up with the [HDMI Cable B] provided.
2. Turn on the TV display by pressing the **ⓘ/I** button.
3. Press the **INPUT** button on the front of the *Toshiba TV* to set the Input to **HDMI 3**



4. Turn on the Soundbar by pressing the **ⓘ** button. Then press the **F.** button on the top of the *Samsung Soundbar* or the [**SOURCE**] button on the remote control to set the mode to **D.IN**

